

ACC-EPM

External Page Module Product Installation Drawing

Document 52209 Rev A 5/20/03 ECN 03-215

The ACC-EPM External Page Module provides connections for an external nonemergency page system. Refer to the technical manual Document #51889 for information on wiring.

CAUTION! Make sure to observe all of the following precautions:

- Remove all power (AC and DC) before installing or removing any modules since damage to components may occur if power remains applied.
- Circuit boards contain static-sensitive components. Always ground yourself with a proper wrist strap before handling any boards so that static charges are removed from the body. Use static suppressive packaging to protect electronic assemblies.

ACC-EPM Installation

1. Make certain that AC and DC power have been removed from the panel.
2. If this module is a replacement for an existing ACC-EPM, remove the screw which secures the module to the standoff on the main circuit board and unplug the module from connector P13.
3. Align the new ACC-EPM module connector J1 over connector P13 on the main circuit board and press into place being careful not to bend or break any pins.
4. Secure the module to the standoff with the screw removed in Step 2.
5. Wire the external page circuit as described in the technical manual Document #51889.
6. Reapply AC and DC power and test the panel for proper operation.

