

```
////////////////////////////////////  
//                                                                    //  
//                                                                    //  
//          Lite-Calcs 2.1 INSTALLATION NOTES                          //  
//                                                                    //  
//                                                                    //  
////////////////////////////////////
```

SYSTEM REQUIREMENTS

To run Lite-Calcs, you should have the following:

- IBM-PC compatible computer
- Microsoft® Windows 98, 2000, XP, or Vista
- CD-ROM or CD-R drive
- 35 MB of available hard drive space
- Video resolution of at least 800 x 600 pixels
- 16 MB RAM (32 MB recommended)
- VGA display adaptor with 256 colors (16-bit recommended)
- Adobe® Acrobat Reader software installed
- Microsoft® Internet Explorer or compatible Web browser (optional)

INSTALLATION

Lite-Calcs requires that you have certain Microsoft components (e.g., DCOM95, MDAC25) to function properly. If your computer does not have these components installed, the setup will automatically install these components.

To install Lite-Calcs

Close all programs, including resident programs on the Taskbar, then follow these steps:

1. Insert the Firelite Resource CD into your CD-ROM drive.
2. Extract LiteCalcs2_1.zip onto your hard drive.
3. Double-Click on the LiteCalcs2_1.exe to start the installation process.

When the installation is complete, you may be prompted to reboot your system. If you do not reboot your system, Lite-Calcs will not run properly.

ACROBAT READER

Viewing data sheets From within Lite-Calcs requires Adobe Acrobat Reader. If you do not have Adobe Acrobat Reader installed, you can get the latest version from <http://www.adobe.com>.

For additional information on using Lite-Calcs, refer to the Lite-Calcs Help file.